

# GERMANY WWII E-75 HEAVY TANK WITH 128MM FLAK 40 GUN





ITEM NO: UA72136

Delivered for testing in late 1937 and completed testing successfully. The your wayighed nearly 12 tonnes in its firing position, with the result that its barrel had to be removed for transport. Limited service te sting show to be was impractical, so in 1938 other solutions were considered

The eventual solution was to simplify the firing platform, based on the assumption it would always be securely bolted into concrete. The total weight of the Flakzwilling twin-gun mount system reached 25.7 tonnes, making it practically impossible to tow cross-country. In the end, this mattered little since by the time the gun enters. group 1942, it was used in primary static defensive applications. There were four twin mounts on the fortified anti-aircraft Zno Tower and they were also on other flak towers protecting Berlin, Hamburg, and Vienna. During the Battle of Berlin, the guns with 1200 Town vere user successfully to support ground forces, where the heavy 128 mm shells obliterated Soviet armor, especially when the from the side. The rush to capture the Reichstag led to dozens of tanks being destroyed. Approximately 200 were nounce on railcars, providing limited mobility.

The gun fired a 27.9 kg (57.2-pound) si ell at 880 m/s (2,890 ft/s) to a maximum ceiling of 14,800 m (48,556 ft). Compared with the 88 mm FlaK 18 & 36, the FlaK 40 use: a punder charge four times as great.

#### **•READ BEFORE ASSEMBLY**

- 1. When you use glue or paint, do not not a same, and us a in a well-ventiated room.
- 2. Take extra care in handling rnote exh parts in order to avoid injury
- 3. When you take parts off the runner frame, use modeling scissors and trim excess plastic with a cutter una his.
- 4. Glue and paint are not included.
- 5. This product is only suitable for experienced more than 14 years old.

### SUPERGLUE

? OPTION 选择





NO CEMENT











## CUT/REMOVE



3. 从胶架中取出部件时,应用模型专用剪,并用界刀或小锉除去多余的

1. 勿於近火处使用胶水或油漆,并 打开窗户保持空气流通。

2. 取蚀刻片时应特别注意安全, 防止利边划伤手指。

5. 本产品不适合14岁以下没有经验的模型爱好者。

4. 请使用塑料胶水和油漆,模型内不含。





### **DECAL APPLICATION**

- 1.Cut off decal from sheet.
- 2.Dip the decal in tepid water 40° C for about 10 sec.and place on a clean
- 3. Hold the backing sheet edge and slide decal onto the model.
- 4. Move decal into position by wetting decal with finger.
- 5. Press decal gently down with a soft cloth until excess water and air bubbles are gone.

### 水贴纸的使用:

- 1. 从水贴纸上剪下印花。
- 2. 将印花放入温水中浸10秒, 然后放在干净布上。
- 3. 拿着印花纸板将印花移到模型上。
- 4. 手指蘸水将印花移到适当的位置。
- 5. 用软布轻压印花直至不干, 汽泡消失。









































