


# WWII GERMAN V1 MISSILE RAILWAY CAR



Both sides


ITEM NO:UA72171

## ●READ BEFORE ASSEMBLY


1. When you use glue or paint, do not near flame, and use in a well-ventilated room.
2. Take extra care in handling photo etch parts in order to avoid injury.
3. When you take parts off the runner frame, use modeling scissors and trim excess plastic with a cutter or a file.
4. Glue and paint are not included.
5. This product is only suitable for experienced more than 14 years old.

## ●装配之前仔细阅读:


1. 勿於近火处使用胶水或油漆, 并 打开窗户保持空气流通。
2. 取蚀刻片时应特别注意安全, 防止利边划伤手指。
3. 从胶架上取出部件时, 应用模型专用剪, 并用界刀或小锉除去多余的塑料。
4. 请使用塑料胶水和油漆, 模型内不含。
5. 本产品不适合14岁以下没有经验的模型爱好者。




OPTION  
选择



NO CEMENT  
不涂胶水



DECAL  
贴纸







## DECAL APPLICATION

1. Cut off decal from sheet.
2. Dip the decal in tepid water 40° C for about 10 sec. and place on a clean cloth.
3. Hold the backing sheet edge and slide decal onto the model.
4. Move decal into position by wetting decal with finger.
5. Press decal gently down with a soft cloth until excess water and air bubbles are gone.

## 水贴纸的使用:


1. 从水贴上剪下印花。
2. 将印花放入温水中浸10秒, 然后放在干净布上。
3. 拿着印花纸将印花移到模型上。
4. 手指蘸水将印花移到适当的位置。
5. 用软布轻压印花直至不干, 气泡消失。






1

L X 4




S X 8




2

Q X 4




F X 2







3




4




5




6



7




8







9




10




11




12



13



14







# WWII GERMAN V1 MISSILE RAILWAY CAR

1/72 Scale

modelcollect



Both sides



A.MIG-008  
RAL 7021 DUNKELGRAU

For a better result when painting your model it is highly advisable to follow weathering techniques.