## GERMAN WWII E-100 SUPER HEAVY TANK WITH 128MM FLAK 40 GUN





ITEM NO: UA72133

The Panzerkampfwagen E-100 (Gerät 383) (TG-01) was a German superheavy tank design developed near the end of World War II. It was to also be the basis for a heavy artillery system, an anti-aircraft vehicle, and a heavy tank destroyer. However, the development of these last was never started do to the end of World War II, by which time only the E-100's chassis was partially completed. It was shipped to the United Kingdom for testing, and was scrapped.

The basic design was ordered by the Waffenamt as a parallel develorment to the Porsche Maus in June 1943. It was the heaviest of the Entwicking (E) series of vehicles, meant to standardize as many components as cossible. There was going to be an E-5, E-10, E-25, E-50, E-75 and finally E-100. In November 1942, Krupp suggested a design weighing 155 to compared to the 188 tons of the Maus - but still using the Maus turret. The ember 1942, Krupp suggested a design weighing 130 tons which was many of the same components as the Tiger tank with Maus turret — would to as the "Tiger-Maus". Weight savings were to be from thinner armount, and narrowing and shortening the vehicle.

In 1944 Hitler ordered the development of super hervy; anks to stop, work on the E-100 however continued at a very low priority; with only three Adler employees available to assemble the prototype.

#### Specifications

Weight Crew Armor	140 tonnes (154 short tons; 138 long tons) 6 150–200 millimetres (5.9–7.9 in) (hull front)
	120–150 millimetres (4.7–5.9 in)
	(hull sides and rear)
	40 millimetres (1.6 in) (hull top)
	40-80 millimetres (1.6-3.1 in) (hull bottom)
	200 millimetres (7.9 in) (turret front)
	80-150 millimetres (3.1-5.9 in)
	(turret sides and rear)
	40 millimetres (1.6 in) (turret top)
Main armament	12.8 cm KwK 44 L/55
	15 cm KwK 44 L/38, or
	17.3 cm Kwk 44
	(Note: the 17.3 cm Kwk 44 was only going
	to be mounted on
	the non-turreted tank destroyer like variant
	of the E-100)
Power/weight	4.52 hp/ton (prototype)5.48 hp/ton (proposed)
Suspension	Belleville washer coil spring
Operational range	190 km (120 ml) (road)
Speed	40 km/h (25 mph)

The prototype had a HL 230P30 engine and Olvar transmission fitted. The HL 230 was the same V-12 engine and that was used on the Tiger II and Panther tanks. It was suitable for the 45-tonne Panther, underpowered for the 70-tonne Tiger II, and grossly under-powered for a 140-tonne design. The chassis of the prototype was virtually completed however it lacked a turret that would have been fitted with the 15 cm KwK 44 gun. The final version was to be powered by an HL234 producing 850 hp mated to a Mekydro transmission. A 17 cm KwK 44 was proposed as the final armament. Suspension was to be the externally mounted Belleville Washer type. The hull had sloped armor, typical of post-1943 design. Wheels were overlapped, similar to the Tiger II and Panther tank, and no longer interleaved as with the Schachtellaufwerk suspension of the original Tiger I.

#### ●READ BEFORE ASSEMBLY

- 1. When you use glue or paint, do not near flame, and use in a well-ventiated room.
- 2. Take extra care in handling phote etch parts in order to avoid injury
- When you take parts off the runner frame, use modeling scissors and trim excess plastic with a cutter or a file.
- 4. Glue and paint are not included.
- 5. This product is only suitable for experienced more than 14 years old.



SUPERGLUE 强力胶 Ô

WE I GHT

-

MAKE HOLE 钻孔

钻孔



OPTION 选择







DECAL

#### DECAL APPLICATION

- 1.Cut off decal from sheet.
- 2.Dip the decal in tepid water 40  $^{\circ}\,$  C for about 10 sec.and place on a clean cloth.
- 3. Hold the backing sheet edge and slide decal onto the model.
- 4. Move decal into position by wetting decal with finger.
- 5. Press decal gently down with a soft cloth until excess water and air bubbles are gone

#### ●装配之前仔细阅读:

- 1, 勿於近火处使用胶水或油漆, 并 打开窗户保持空气流通。
- 2. 取蚀刻片时应特别注意安全, 防止利边划伤手指。
- 3. 从胶架中取出部件时,应用模型专用剪,并用界刀或小锉除去多余的 胶料。
- 4. 请使用塑料胶水和油漆、模型内不含。
- 5. 本产品不适合14岁以下没有经验的模型爱好者。



CUT/REMOVE 切除




BEN





#### 水贴纸的使用:


- 1. 从水贴纸上剪下印花。
- 2. 将印花放入温水中浸10秒, 然后放在干净布上。
- 3. 拿着印花纸板将印花移到模型上。
- 4. 手指蘸水将印花移到适当的位置。
- 5. 用软布轻压印花直至不干, 汽泡消失。





Track X 2
























































### modelcollect

# GERMAN WWII E-100 SUPER HEAVY TANK WITH 128MM FLAK 40 GUN



